

# How to Drive Steel Sheet Piles



*American  
Piledriving  
Equipment, Inc.*

***APE Pile Driving School***



# What Is a Steel Sheet Pile?



Sheets of Steel plates that interconnect.

# Examples






# Examples







# Example



# Examples





# What Do They Look Like?







# Various Types at a Glance


Z Sections



U Sections



Straight Web Sections





# Job Examples



# Sheet Pile

## Terminology:

### *Section Data: Name*



Section Name: Manufacturer's Designation to identify the section. Example: PZ-27


PZ-27 means Z-Shaped with 27 pounds Per square foot.

# Job Examples




# Sheet Pile

**Terminology:** *Producer and Country of Origin*



Germany, England, Japan,  
USA, Korea, Luxemburg, Etc.





# Sheet Pile Terminology:

*Shape: 4 Basic Types*

## 1. Z-type (Z)

Arbed PU



**PZ-22**

**PZ-27**

**PZ-35**

**PZ-40**

Used for Intermediate to Deep Wall Construction

# Sheet Pile Terminology:

*Shape: 4 Basic Types*

2. U-type (U)



Used For Applications Similar to  
Z-Piles

# Sheet Pile Terminology:

*Shape: 4 Basic Types*

3. Flat Sheets (*F*)




Used to form Cellular  
Cofferdams





# Flat Sheets





ar c




# Examples



# Sheet Pile Terminology:


*Shape: 4 Basic Types*

## 4. Arch (A)




Used For Shallower Wall Construction. Also Comes in Light Weights or Gauges.

# Description




Two Z Shaped Steel Sheet Piles Interlocked together to form a “pair” or “double sheet”.

# Types of Steel Sheet Piles: Trench Shoring HOESH



Note: No interlocks

# Types of Interlocks




PZ-27

## Ball and Socket Type

### *Positive Points:*

- *Easy to thread. Hangs up less.*
- *Pile Crews Desire This Type of Interlock*
- *Super Rugged Interlock*
- *Great for Repeated Use.*
- *Easy to Drive because Interlock displaces less soil*

# Types of Interlocks



## Double Jaw

### *Positive Points:*

- *Proven Track Record*
- *Tight interlocks-Less Seepage*
- *Strong for repeated use.*
- *Good in Hard Driving Situations*
- *Small profile Interlocks*



## Single Jaw

### • *Negative:*

- *Less Swing*
- *Hangs up more*
- *Holds up good but not as good as the ball and socket type interlock.*



# Types of Interlocks



## Double Hook

*Positive Points:*      *Proven Track Record*  
*Negative:*                *Limited Swing*


# Types of Interlocks



## Cold Rolled Hook and Grip

- Avoid if hard driving
- Avoid if sealing out water


# Types of Interlocks



Thumb and Finger- Three Point Contact


Thumb and Finger Interlock is Used on Flat Sheet Piles. Interlock is rated by Tension Strength. Used for Cofferdams.

# Types of Interlocks



Thumb and Finger- One Point Contact

# Reading Sheet Pile Dimensions: *Section Area*




Cross-sectional area is listed as square inches per foot of wall.

Areas shown for flat piling are based on the single section only.




# Reading Sheet Pile Dimensions: *Nominal Width*



Centerline from Interlock to Interlock




# Reading Sheet Pile Dimensions: *Weight*



Weight of Square Foot of Wall



# Reading Sheet Pile Dimensions: *Wall Depth*





Distance between outboard and  
inboard Faces






# Reading Sheet Pile Dimensions: *Wall Web and Flange*





# Reading Sheet Pile Dimensions: *Moment of Inertia*



Product of cross-sectional area and squared distance from a reference axis



# Reading Sheet Pile Dimensions: *Section Modulus*



What to Consider Beyond  
Section Modulus and Moment of  
Inertia.

Choosing The Right Sheet Pile  
for The Job Based on Driving  
Conditions and Dewatering  
Requirements.

# Understanding the Difference Between Hot Rolled and Cold Formed.



# Sheet Pile Terminology: Hot Rolled (HR)





# Hot Rolled Steel Sheets

## *Good Points:*

- Proven track record since early 1900's
- Tight interlock for good water seal
- Proven procedures to reduce seepage based on 100 years of data
- Less interlock slop reduces tendency to lean and reduces template criteria
- Strong interlock for hard driving
- Can be made with thick (up to  $\frac{3}{4}$  inch) wall for super hard driving
- Web layout superior to cold formed (for hammer energy transfer)
- More elastic at angle area (cold forming process reduces elasticity)
- Excellent for reuse due to strong interlocks
- Available for rent and rental/purchase



# Hot Rolled Steel Sheets




## *Bad Points:*

- Costs more than cold formed
- Restricted lengths 25 feet to 60'
- Lengths restricted to 5' intervals
- Special lengths are special order
- May weigh more per foot of wall
- May not be necessary in super soft soils



# Cold Formed Steel Sheet Piles Are:

**Cold Formed From Steel  
Sheet Rolls Called Scalp or  
Coils**




# Cold Formed Steel Sheets

## *Good Points:*

- Much Cheaper to make than hot rolled
- Can get cut to any length and quantity
- Fast delivery and production
- 15 to 20 different shapes & thicknesses
- Good for soft driving but requires careful alignment
- Greater swing than hot rolled allows greater curves


# Cold Formed Steel Sheets

## *Bad Points:*




- Weak interlocks
- Cold formed sheet interlocks much larger than hot- harder to clamp\*
- Sloppy interlocks get jammed easy from soil entering
- Seepage problems
- Brittle at bent areas due to dynamic loading when cold formed
- Interlocks fail in hard soils or when striking obstacles
- Web is longer. Vibratory hammers will rip out tops
- Not good for jobs where sheets must be reused several times
- Not available for rent because interlock failures
- Requires more attention when driving

# Jaws on Cold Formed Interlocks




# Interlock Jamming




Hot rolled sheets have tighter tolerances that keep larger particles out. Large particles cause hitch hiking of the sheets. Hitch hiking

# Dynamic Loading



Bending during cold forming loads areas.

# Driving Methods- Easy Driving-pitch and Drive



- *Soft Driving*
- *No obstacles*
- *Short Piles*
- *Smart crew*
- *Good sheets*
- *Light Vibro*

# Examples- Soft Soils, Short Sheets






Pitch and drive




# Driving Methods

Use at Least a Four Foot Level


Use a String Bob



# Driving Methods-other than soft



1



2

Two templates or more. Upper and Lower.

# Example of Double Templates



Upper template should be substantial fraction of the pile length.

# Driving Methods

## Gaining or Loosing





Figure 9.3


Driving Methods-  
Leaning  
Stop!  
Take Corrective Action.



# Methods-leaning Corrections



In conjunction with the above method, the hammer can be placed off centre of the pair of piles towards the last driven piles.




When, in spite of all precautions, a lean cannot be eliminated, taper piles must be employed to correct the error.



# Impact Hammers

## Things to consider:

- *Heavy ram, shorter stroke*
- *Ram weight should be 1.5 to 2 times the combined pile and cap weight*
- *Diesel hammer may be best choice*
- *Leader mounted*
- *Good drive cap to pile fit*
- *Drive in shorter steps*



# Impact Hammers-drive Caps







**Diesel Hammer**




# Understanding Vibros


Suppressor

Gearbox

Clamp Device




# Vibro Suppressor- rubber Springs




Isolates vibro action from crane line.

# Vibro of Rotating Eccentrics



Paired  
Eccentrics

Eccentric



# Four Strokes of the Eccentric

1 work



Forces the vibro and the casing downward

2



Nothing happens. Each eccentric cancels other out.

3 work



Both eccentrics for vibro and casing upward


4



Nothing happens. Each eccentric cancels other out.

# Vibro-Driver/Extractors

Eccentric moment



Eccentric moment = distance between the center of rotation and the center of gravity  $\times$  the total mass of the eccentric.

# Example of calculating eccentric moment of one eccentric:

Equation:

Distance between


*Center of Rotation*

and

*Center of Gravity*

Multiplied by


The Mass



2 times 500 equals: 1,000 inch pounds




Eccentric moment of a vibro is measurement of all eccentrics combined.




If each eccentric has 1,000 in-lbs then the vibro has a total of 2,000 in-lbs.

Some vibros Have Many Small Eccentrics to  
Get a Large Total Inch Pounds While Others  
Have Less Eccentrics That Are Bigger.




More vibrating weight  
Less amplitude




Less vibrating weight  
More amplitude

# Smaller Weights Means More Bearings, Shafts, Gears.



More parts



Less parts

# Amplitude

$$A = \frac{2 \times Mt}{Mv}$$

$Mv$

Mt = Eccentric Moment in inch pounds


Mv = Total Vibrating Weight


A = Amplitude in inches

Vibrating weight: Mv

The vibrating weight is the sum of all the weights of the vibrating mass.

- B: Dynamic weight (vibrating mass)
- C: Clamping device including all plates or clamps
- D: Pile weight






Vibrating mass: 6500 lb


Amplitude

4000 in-lb.



Vibrating mass: 5000 lb


The hammer on the left has the same eccentric moment but less amplitude because the vibrating mass is heavier.



Amplitude will decrease  
with increase of pile  
weight. Big piles need bigger vibros  
to offset loss of amplitude.

# Amplitude

Amplitude will decrease with increase of:



- Pile weight
- Soil resistance
- Weights, gears, shafts, hoses, motors
- Extra clamp attachments
- Anything that increases vibrating mass.

$$\text{Amplitude} = \frac{2 \times \text{EM}}{\text{VM}}$$

EM: Eccentric Moment



VM: Vibrating Mass

# VPM

# CPM

Frequency (Vibrations Per Minute) or (Cycles Per Minute)

Frequency is the rotational speed of the vibro eccentrics.





# Drive Force (Dynamic Force)

(Cycles per minute)

$$\text{Drive Force} = \frac{\text{Eccentric Moment} \times 0.142 \times \text{Frequency squared}}{1,000,000}$$

**Example:**

Moment: 4400 in-lb.


Frequency: 1600 Cycles per minute

$$\frac{4400 \times 0.0142 \times 1600 \times 1600}{1,000,000} = 159.94 \text{ Tons}$$

**Drive Force**


# How Frequency Matters

1100 cpm



4000 in-lb.

1600 cpm




$$\frac{4400 \times 0.0142 \times 1100 \times 1100}{1,000,000} = 75 \text{ tons}$$

$$159.94 = \frac{4400 \times 0.0142 \times 1600 \times 1600}{1,000,000}$$

# Higher Frequency Dramatically Increases Drive Force Because Frequency is squared.


1100 cpm

5208 in-lbs



1600 cpm



4400 in-lbs



$$\frac{5208 \times 0.0142 \times 1100 \times 1100}{1,000,000} = 89 \text{ tons}$$


$$159.94 = \frac{4400 \times 0.0142 \times 1600 \times 1600}{1,000,000}$$

# Vibro Jaws



# Vibro Clamps- basic Rules


- Wait for hammer to come to speed
- Clamp in center
- Clamp always in line with pile axis
- Avoid clamping on interlocks
- All of teeth in work
- Watch jaws and interlocks for heat
- Do not pull or drive vibro until speed is reached
- Do not open until vibro stops moving
- Melting interlocks means jaws are also taking a beating



# Jaws-watch the Interlocks

Do Not Crush Interlocks

Special deeper Jaws



Model 400  
on Sheets



Hard  
Driving  
Required  
The  
Use  
Of  
Super  
Vibro.

Sheet piles for Air Force missile silos.


# Pile Buck Tools for Driving Sheets

This tool holds leading sheet pile to lower guide.





# Stab Cat



OPEN WHEELS AND JAWS - REMOVE BOTH COUPONS AND TURN COUPONS UP-SIDE DOWN - RE-INSTALL - TIGHTEN WHEELS AND JAWS - THE INTERLOCK WILL BE "PITCHED" LEFT - LOOSEN RIGHT HAND JAW CRANK AND TIGHTEN LEFT HAND JAW CRANK UNTIL 12" COUPON (SUSPENDED SHEET) INTERLOCK IS EXACTLY IN CENTER OF RECEIVING INTERLOCK - TIGHTEN BOTH JAW HAND CRANKS, KEEPING INTERLOCK CENTERED - LOOSEN SET SCREW IN LEFT HAND LOCKING COLLAR - SLIDE LOCKING COLLAR AGAINST JAW POST AND RE-TIGHTEN SET SCREW.

**SET UP IS FOR SINGLE OR DOUBLE SHEETS**

# APE Rules for Driving Sheets



1. Never stand under foundation equipment.
2. Start with piles in good condition.
3. Put all clamp teeth in contact with pile.
4. Drive in steps eight feet or less.
5. Keep sheets plumb.
6. Come up to speed before doing work.
7. No dancing – avoid densification.
8. Drive past obstacles and then go back.
9. Backhoe on site to remove obstacles.
10. Lead with the ball of the sheet pile.
11. Probe the pile if it appears stuck.
12. Never rush the sheet pile foreman.
13. Slow and plumb and the job will get done.
14. Melted inner locks = piles out of plumb.
15. Low clamp pressure means jaw failures.
16. Wait for vibro to get to full speed then pull.
17. Don't over excavate – lower the ring.
18. Look at the jaws during driving.
19. Beware of cracked or broken sheets.
20. In sandy soils drive faster.
21. In clay, amplitude is everything.
22. Low drive pressure means easy work.
23. High pressure means friction on piles.
24. Over 4500 psi means bigger hammer needed.
25. No amplitude means bigger hammer needed.
26. Check clamp bolts each morning.
27. Read the manual – know your machine.
28. Attach whip line to pile when pulling.
29. Know your line pull.
30. Extract straight – look at boom and cable.
31. Give boom stops some room.
32. Stalled engine means dirty fuel filters.
33. Never stand under foundation equipment.
34. GoAPE!

[www.americanpiledriving.com](http://www.americanpiledriving.com)



Call APE: (800) 248-8498